



L5LB Manual Hoist Recommended Spare Parts 3/4 to 9 Ton

Name	Parts Per Hoist	3/4 Ton	1 Ton	1 1/2 Ton	2 Ton	2 3/4 Ton	3 Ton	6 Ton	9 Ton
Top Hook Assembly	1							L5BU0601001 L5BA0902001	L5BA0902001
Bottom Hook Assembly	1							L5BA0632001	L5BA0902001
Top Hook Comp. Set	1	L5BU0081001	L5BU0101001	L5BU0151001	L5BU0201001	L5BU0281001	L5BU0301001		
Bottom Hook Comp. Set	1	L5BU0081021	L5BU0101021	L5BU0151021	L5BU0201021	L5BU0281021	L5BU0301021		
Latch Assembly	2	L5BA0081071	L5BA0101071	L5BA0161071	L5BA0251071	L5BA0251071	L5BA0321071	L5BA0631071	L5BA0901071
Chain Pin	1	L4041008		M3041015	L5BA0259041	L5BA0259041	L4BH0309041	L4BH0609041	
Slotted Nut	1	M3049005		M3049010		M3049020			
Split Pin	1	9009402		9009411			9009412		
Pinion	1	L5BA0089111	L5BA0169111	L5BA0169111	L5BA0259111	L5BA0259111		L5BA0329111	
Gear #2	2	L5BA0089112	L5BA0169112	L5BA0169112	L5BA0259112	L5BA0259112		L5BA0329112	
Chain Guide	2	L5BA0089161	L5BA0169161	L5BA0169161	L5BA0259161	L5BA0259161		L5BA0329161	
Pawl Spring	2	L5BA0089158	L5BA0169158	L5BA0169158	L5BA0259158	L5BA0259158		L5BA0329158	
Snap Ring	2			L4188008				L4188015	
Friction Plate	2			L4151008				L4151015	
Lever Assembly	1	L5BA0086211	L5BA0166211		L5BA0166211			L5BA0326211	
Brake Spring	1			L4207008				L4207015	
Cam Guide	1			L5BA0089203				L4203015	
Free Chain Spring	1			L4205008				L4205015	
Spring Holder	1			L5BA0089208				L5BA0329208	